




Camera Bracket Mounting Quick Start Guide

Thank you for purchasing our product. This manual is applicable to the wall mounting bracket and the ceiling mounting bracket of the fisheye camera. All pictures in this manual are for reference only.


Mounting Examples




Installation

Before installation, please make sure the wall or ceiling is strong enough to withstand three times the weight of the camera and the bracket. Please install your camera and bracket in a dry environment. Here we will introduce the installation of the wall mounting bracket and the ceiling mounting bracket of the fisheye camera.

• Ceiling Mounting





Remove the fixed ring from the gap of the camera and then open the cover of the micro SD card slot. After that, insert a micro SD card.

Remove the fixed ring from the gap of the camera

and then open the cover of the micro SD card


slot. After that, insert a micro SD card.



Install the cover of micro SD card slot and then fasten the camera onto the bracket with screws.



Install the fixed ring back to the camera and then fix the bracket with screws.



Install the cover of micro SD card slot and then

fasten the camera onto the bracket with screws.

Install the fixed ring back to the camera and then

fix the bracket with screws.