

User Manual

Model DVA30 AC Voltage and Current Detector



Introduction

Congratulations on your purchase of the Extech DVA30. This instrument is shipped fully tested and calibrated and, with proper use, will provide years of reliable service. Please visit our website (<u>www.extech.com</u>) to check for the latest version of this User Guide, Product Updates, and Customer Support.

Features

- Non-Contact Voltage Detection.
- Non-Contact Current Detection.
- Identify "hot" conductors and terminals.
- Trace current carrying conductors behind walls and in conduit.
- Sensitivity adjusts to "home" in on conductors.
- Locate hidden wires.

International Safety Symbols



This symbol, adjacent to another symbol or terminal, indicates that the user must refer to the manual for further information.



This symbol, adjacent to a terminal, indicates that, under normal use, hazardous voltages may be present.

Safety Precautions

- 1. Improper use of this meter can cause damage, shock, injury or death. Read and understand this manual before use.
- 2. Secure any covers or battery doors before use.
- 3. Inspect the condition of the meter for any damage before use.
- 4. Remove the batteries from the meter if the meter is to be stored for long periods.

Tester Description

- 1. Current Sensor and LED
- 2. Current Detector "ON" LED
- 3. Current Detector Sensitivity adjustment
- 4. Current/Voltage/OFF function selector switch
- 5. Voltage Sensor and LED
- 6. Voltage Detector "ON" LED
- 7. Voltage Detector Sensitivity adjustment
- 8. Audible beeper



Operation

- **WARNING:** Risk of Electrocution. Before use, always test the detector on a known live circuit to verify proper operation.
- **NOTE on RF Interference:** In the voltage mode, RF signals in close proximity to the detector may cause the voltage light and beeper to latch into a constant tone and light indication. Wait until the RF signal has disappeared before proceeding with voltage detection.

VOLTAGE DETECTION

- 1. Slide the Function switch to the Voltage position.
- 2. The "VOLTAGE" LED will light. If the LED is dim or does not light, replace the batteries.
- 3. Set the Sensitivity adjustment to max.
- 4. If the detector begins to beep/flash, slowly turn the sensitivity down until the beep/flash stops.
- 5. Touch the detector voltage sensor to the hot conductor or insert into the hot side of the electrical outlet.
- 6. If AC voltage is present, the detector light will flash, and the audible beeper will sound.
- 7. Adjust the sensitivity as needed to zero-in and identify the live conductor.

CURRENT DETECTION

NOTE: There must be a load on the circuit (current flow) for the current detection function to work.

- 1. Slide the Function switch to the Current position.
- 2. The "CURRENT" LED will light. If the LED is dim or does not light, replace the batteries.
- 3. Set the Sensitivity adjustment to the max position.
- 4. If detector begins to beep/flash, slowly turn the sensitivity down until the beep/flash stops.
- 5. Move the detector current sensor near the current carrying conductor until the current tip flashes and beeper sounds.
- 6. Slowly reduce the sensitivity and reduce the distance between the sensor and conductor to zero-in and identify the conductor.

4



Max. Sensitivity



BATTERY REPLACEMENT

- 1. Turn power OFF.
- 2. Slide the pocket clip off by pushing it down (as shown) to access batteries.
- 3. Replace the four LR44 batteries. The negative sides of the batteries face in the same direction, as shown. The positive sides of the batteries face in the opposite direction.



Battery Safety Reminders

- Please dispose of batteries responsibly; observe local, state, national regulations.
- Never dispose of batteries in a fire; batteries may explode or leak.
- Never mix battery types; install new batteries of the same type.

Specifica	tions
-----------	-------

Voltage detection	12V to 600VAC
Current sensitivity	200mA (0.2A) AC at 0.2"
Audible indication	Beeper (Voltage & Current)
Visible indication	Flashing LED (Voltage & Current)
Frequency range	50 to 500Hz
Operating Temperature	14 to 122°F (-10°C to 50°C)
Operating Humidity	< 80% RH
Altitude	< 2000m
Power supply	(4) LR44 batteries or equivalent
Weight	2.1 oz. (60g)
Dimensions	7.6 x 1.2 x 0.9" (192x31x24mm)
IEC 1010	Category III 600V
Indoor use	

Typical Applications

VOLTAGE







Locate breaks in wires

Identify hot terminal and polarity

CURRENT



Trace current flow behind walls

Detect current flow through conduit or shielding



Compare current flow on branch circuits



Check/Monitor current flow to appliances

Two-year Warranty

Teledyne FLIR warrants this Extech brand instrument to be free of defects in parts and workmanship for **two years** from date of shipment (a six-month limited warranty applies to sensors and cables). To view the full warranty text please visit: https://www.flir.com/support-center/warranty/instruments/extech-product-warranty/.

Calibration and Repair Services

Teledyne FLIR offers calibration and repair services for the Extech brand products we sell. We offer NIST traceable calibration for most of our products. Contact us for information on calibration and repair availability, refer to the contact information below. Annual calibrations should be performed to verify meter performance and accuracy. Product specifications are subject to change without notice. Please visit our website for the most up-to-date product information: www.flir.com/landing/extech/.

Contact Customer Support

Customer Support Telephone List: <u>https://support.flir.com/contact</u> Calibration, Repair, and Returns: <u>repair@extech.com</u> Technical Support: <u>https://support.flir.com</u>

Copyright $\ensuremath{\mathbb{C}}$ 2023 Teledyne FLIR Commercial Systems, Inc.

All rights reserved including the right of reproduction in whole or in part in any form <u>www.extech.com</u>

This document does not contain any export-controlled information

